



DR-120导轨式

接线位置：7位端子

L , N : AC输入

: 接大地

-V : DC输出负端

+V : DC输出正端

输入电压范围 AC input voltage range	88-132VAC/176-264VAC
输入电流 Input current	3.3A/115V 2A/230V
冲击电流 AC inrush current	冷启动电流 30A/115V 60A/230V Cold-start current 30A/115V 60A/230V
漏电电流 Leakage current	<3.5mA/240VAC
直流电压可调范围 DC adjustable range	额定输出电压的±10% ±10% rated output voltage
过载保护 Over load protection	105-150% 切断输出，自动恢复 105-150% hiccup mode,auto-recovery
过电压保护 Over-voltage protection	121-142%
启动、上升、保持时间 Setup rise hold up time	500ms 70ms 30ms
耐压性 Withstand voltage	I/P-O/P: 3KVAC 1minute I/P-FG: 1.5KVAC 1minute
工作温度、湿度 Working temperature	-10 ~ +60
重量/包装 Weight/packing	0.8kg.20pcs/16kg/1.1CUFT

型号type	输出Output	差值Error	范围Range	效率Efficiency
DR-120-12	12V , 0-10A	±2%	80mV	80%
DR-120-24	24V , 0-5.0A	±1%	80mV	84%
DR-120-48	48V , 0-2.5A	±1%	120mV	85%

NOTE:

1. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25 °C of ambient temperature.
2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1uf & 47uf parallel capacitor.
3. Tolerance : includes set up tolerance, line regulation and load regulation.
4. The power supply is considered a component which will be installed into a final equipment. The final equipment must be re-confirmed that it still meets EMC directives.
5. If the power supply is short-circuited under no load, it will recover automatically when short-circuit is removed.